



**Find scraper from tool kits bag,
use scraper to make the wire straight**